


Item	Qty	Part Number	Description
1	2	SHV 020 0021 2715	Half Shroud 292-12
2a	1	SHV 020 0021 0716	Hinge Left Side Plate 292-24
2b	1	SHV 020 0021 0716B	Hinge RS Plate+Key Slot 292-20
3	2	SHV 020 0021 2697	Sheave Wheel Half 292-20
4	1	SHV 020 0021 0698	Sheave Tire 1/4" 292-26
4	1	SHV 020 0021 0701	Sheave Tire 5/8" 292-26
4	1	SHV 020 0021 0696	Sheave Tire 9/16" 292-26
4	1	SHV 020 0021 0700	Sheave Tire 3/8" 292-26
4	1	SHV 020 0021 0699	Sheave Tire 5/16" 292-26
4	1	SHV 020 0021 0695	Sheave Tire 7/16" 292-26
5	1	SHV 020 0021 0703	Hinge Trunion Plate 293-24
6	1	SHV 020 0021 2702	Clevis 293-08
7	1	SHV 020 0086 2124	Capscrew 293-07
8	1	SHV 020 0021 2708	Axle 293-06
9	2	SHV 020 0021 0706	Shaft Spacer 293-15
10	2	SHV 020 0021 1709	Bearing Retainer Cover 293-14
13	1	SHV 014 0021 0704	Clevis Pin 293-16
14	1	SHV 014 0086 0126	Clevis Pin Spring 293-19
15	1	SHV 014 0021 0705	Clevis Pin Knob 293-17
16	12	SHV 020 0086 0126	3/8"NC Hex Socket HDCS x 5/8"LG
17	12	SHV 020 0086 0123	3/8"NC Hex Countersunk HDCSx 2"LG
18	12	SHV 020 0086 0127	5/16"NC Hex Button HDCS 3/4" LG
19	1	SHV 014 0021 0717	Side Plate Pin Knob 293-20
20	1	SHV 020 0021 0718	Side Plate Pin, Lock 293-23
21	1	SHV 020 0086 0125	Busing 1.375OD x 1.125 ID x 1.000LG
22	1	SHV 020 0021 0704	Washer 2"OD x 1.375" ID x 1.000 LG
23	1	SHV 020 0021 0719	Side Plate Pin, Stationary 293-21
24	3	SHV 020 0086 6450	Lynch Pin 3/16" Dia.
25	1	SHV 020 0086 P144	Spring Pin 1/4" x 4" LG SS
26	1	SHV 014 0086 0128	Spring Pin 1/8" x 1/2" LG
27	1	SHV 014 0086 0127	Spring Pin 3/16" x 1-1/2" LG
28	2	SHV 020 NUP2 209E	Bearing NN NUP 2209E
29	1	SHV 020 0812 06TN	Thrust Bearing INA81206 TN
30	2	SHV 020 OCR2 2354	Seal CR 22354
31	2	SHV 020 0021 TN09	Locknut TN-09
32	2	SHV 020 000T W109	Lockwasher TW-109
33	1	SHV 014 0086 0129	Spring Pin 3/16" OD x 7/8" LG



34	1	SHV 020 ZERT 5000	1/4" Grease Zert
35	1	SHV 020 0021 0709	Key
36	1	SHV 014 DYN6 6489	Safety Pin 1/8" Dia.
37	2	SHV 020 ORING 224	O-Ring Seal
38	1	SHV 020 LUBE TUBE	Lubrication Tube